



NOTE:
 Hydro-prufe PVC Waterstop must be set into Footing during concrete placement.



ELEVATED SLAB (NON-HYDROSTATIC)
 (OPTION-3)

Scale:	Date:	Drawing #:
NTS	12-08-14	FS-0103