



**NOTE:**  
 Set Hydro-Prufe PVC Flashing collar around steel raker in a full bedding of HP-Liquid Flashing 9800. Clean steel by abrasion methods, prime steel with HP 9112 Primer prior to HP-Liquid Flashing. Ensure no HP-Liquid Flashing 9800 is applied to seam area. Let HP-Liquid Flashing 9800 cure for 12 hours prior to Hot Air Weld seams.

DETAIL NAME:

PIPE RAKER IN SLAB

Scale:

NTS

Date:

12-08-14

Drawing #:

US-0114