



PVC Waterstop with SK Tape,
Hot Air weld to Hydro-Prufe 80 mil
membrane
HP - 9800 Termination Flashing

Set 60mil Starter Strip Flashing in heavy
bedding of HG-9800 Liquid Flashing,
abrade steel, clean (or blast), prime steel
and 60mil Hydro-Flashing with HG-9112
Primer. (Let cure).

NOTES:
1. Burn out holes for rebars shall be performed
prior to waterproofing installation.



DETAIL NAME:
**SHORED WALL BACK LAGGED
CONDITION**

JOB NAME:

Scale:	Date:	Drawing #:
NTS	03-10-15	SH-0107