



Clean Drain Ring and apply a heavy bedding of SAF-30 at Drain as shown and immediately embed Hydro-Prufe Flashing Strip into wet SAF-30. Install Clamping Ring and Bolt securely.
 (Apply SAF-30 to Drain Body a minimum of ¼" thick)



DETAIL NAME:

DRAIN @ TOPPING SLAB w/o INSULATION

JOB NAME:

Scale:

NTS

Date:

12-01-14

Drawing #:

HP-DR-002