



Clean Drain Ring and apply a heavy bedding of SAF-30 at Drain as shown and immediately embed Hydro-Prufe Flashing Strip into wet SAF-30. Install Clamping Ring and Bolt securely. (Apply SAF-30 to Drain Body a minimum of 1/4" thick)

Tapered Insulation, 60 psi EPS (Expanded Polystyrene) or XPS (Extruded Polystyrene) w/ Slope : 1/4" = 1' to drain.



DETAIL NAME:

**DRAIN DETAIL
WITH TAPERED INSULATION**

Scale:

NTS

Date:

10-27-15

Drawing #:

HP-DR-005