



NOTE:
 Hydro-Prufe PVC Waterstop must be set into Footing during concrete placement.



SLAB ON FOOTING (NON-HYDROSTATIC)
 (OPTION-3)

Scale: NTS Date: 12-08-15 Drawing #: FS-0100