



- ~ Clean PVC Membrane with Solvent Wipe
- ~ Prime PVC Membrane HP-9112
- HP-9800 Liquid Flashing
- Termination Bar
- Fabric Reinforcement
- Hydro-Tuff PB 25
- Hydro-Tuff HFA
- ~ Prime PB-25 with HG-9112
- ~ Apply 90 mil HP-9800 Liquid Flashing over PB-25. Let cure 45 mins to 1 hour
- ~ Apply 2nd coat HP-9800 Liquid Flashing 60-90 mil over cured Base Coat to be used to bed PVC Membrane in .
- ~ Carry min. 12" PVC fold down and immediately set PVC in HP-9800 while still wet and broom PVC Membrane into wet HP-9800.
- Hydro-Prufe 80 PVC Membrane
- Hydro-Ultra Mat B (Bentonite Layer)



DETAIL NAME:  
**TIE IN DETAIL HYDRO-PRUFE TO HYDRO-TUFF  
 (EXTENDED SHORED WALLS)**

JOB NAME:

Scale:	Date:	Drawing #:
NTS	12-10-13	SH-HWS-0105B